

## How to change the handle direction of L730

1. Turn the 4 screws away



2. Take away the plastic cover and collar



3. Loosen the screw of handle and change the handle direction



4. Put the collar, plastic cover and screws back

5. For the inner handle, please change the direction of the spring.

